

wirquin

So Low



Nous vous recommandons de lire intégralement la notice avant de commencer votre installation.

We recommend that you read all the instructions carefully before starting to install your shower.

Wij raden u aan de montagehandleiding aandachtig te lezen vóór u met de plaatsing begint.

Le aconsejamos que lea las instrucciones completamente antes de empezar la instalación.

Wir empfehlen Ihnen, die Montageanweisung vor Beginn der Montage vollständig zu lesen.

Recomendamos que leia totalmente o folheto informativo antes de iniciar a instalação.

Leggere le istruzioni nella loro integralità prima di procedere all'installazione.

Рекомендуем внимательно прочесть инструкцию по сборке перед началом работ.

Vă recomandăm să citiți cu atenție instrucțiunile de montaj, înainte de instalarea produsului.

Σας συστήνουμε να διαβάσετε προσεκτικά τις οδηγίες εγκατάστασης, προτού ξεκινήσετε την εγκατάσταση.

Tout simplement !

217634_A-07/2018



not included

- 1 Mortar/Mortar/Mortel/Mortero/Mörtel/Cimento/Malta/Строительный раствор/Ψάρπ/Τσιμεντοκράμα
- 2 Colle PVC/PVC adhesive/PVC-lijm/Cola de PVC/PVC-Kleber/Cola de PVC/Cola PVC/κлей ПВХ/Adezin PVC/Κόλλα PVC
- 3 Primaire d'accrochage/Primer coat/Hechtprimer/Imprimación de adherencia/Grundierung/Primário de fixação/Primer per piastrelle/Μесто крепления/Grund/Αστάρι πλακιδίων
- 4 Enduit d'imperméabilisation/Sealant/Waterdichtende afdekking/Recubrimiento de impermeabilización/Dichtungsmasse/Camada de impermeabilização/Rivestimento di impermeabilizzazione/Изоляционное покрытие/Ηδρωζολατίε/Στεγανωτικό

not included



